

## BEAMERZ Operating Instructions

BeamerZ uses standard 9-volt batteries. Alkaline or Lithium batteries are acceptable and should provide up to forty hours of operation. Batteries are available at [www.beamerz.net](http://www.beamerz.net).

To install or replace batteries, remove BeamerZ cap with a Phillips screwdriver. Place 9-volt battery in base of BeamerZ as indicated. Use only the screws, washers and o-ring provided with BeamerZ. Replacements are available at [www.beamerz.net](http://www.beamerz.net).

Swipe magnetic fob on keychain against top of cap to turn Beamerz on and off. BeamerZ automatically turn off after 90 minutes of operation.

Each time BeamerZ is turned off and back on, the lighting pattern will change between 'Circular', 'Zig-Zag', "Figure -8" and 'Star'.

Clean BeamerZ with a clean, damp cloth. Do not point high pressure spray directly at BeamerZ! If moisture should enter BeamerZ, remove cap, wipe away moisture and allow to dry before replacing.

**WARNING:** Use on wheels only. Do not use as a warning or safety device. State and local laws vary Check the laws in your area before street use!